

For More Info

Click Here --->



HSM



BETRIEBSANLEITUNG
AKTENVERNICHTER

OPERATING INSTRUCTIONS
PAPER SHREDDER

NOTICE D'UTILISATION
DESTRUCTEUR DE DOCUMENTS

MANUALE OPERATIVO
DISTRUGGIDOCUMENTI

INSTRUCCIONES DE SERVICIO
DESTRUCTORA DE DOCUMENTOS

INSTRUÇÕES DE OPERAÇÃO
DESTRUIDORA DE DOCUMENTOS

GEBRUIKSAANWIJZING
PAPIERVERNIETIGER

BRUGSVEJLEDNING
MAKULERINGSMASKINE

BRUKSANVISNING
DOKUMENTFÖRSTÖRARE

KÄYTTÖOHJE
PAPERINSILPPURI

HSM 125.2



1.270.999.153 – 0510

HSM 125.2

deutsch:	Aktenvernichter HSM 125.2	3 – 6
english:	Paper shredder HSM 125.2	7 – 10
français:	Destructeur de documents HSM 125.2	11 – 14
italiano:	Distruiggidocumenti HSM 125.2	15 – 18
español:	Destructor de documentos HSM 125.2	19 – 22
português:	Destruidora de documentos HSM 125.2	23 – 26
nederlands:	Papiervernietiger HSM 125.2	27 – 30
dansk:	Makuleringsmaskine HSM 125.2	31 – 34
svenska:	Dokumentförstörare HSM 125.2	35 – 38
suomi:	Paperinsilppuri HSM 125.2	39 – 42

For More Info

Click Here --->



Pressen GmbH + Co. KG
Bahnhofstraße 115
D-88682 Salem
Germany

Tel.: +49 (0) 75 53 / 822-0
Fax.: +49 (0) 75 53 / 822-160
E-Mail: support@hsm-online.de
www.hsm-online.de

HSM of America LLC
1075 Andrew Drive
Suite C
West Chester, PA 19380
USA

Phone: 001 610 918 4894
Fax: 001 610 918 4899
E-mail: email@hsmofamerica.com
www.hsmofamerica.com

1. Proper use, warranty

The shredder is designed exclusively for destroying paper. Depending on the cutting type, it can also handle small quantities of the following materials:

Credit and charge cards:

1.9 / 3.9 / 5.8 / 1.9 x 15 / 3.9 x 30 mm only


CDs: 3.9 / 5.8 mm only

Disks: 5.8 mm only

Its sturdy drive mechanism is not damaged by paper clips and staples. Only on machines with safety level HS Level 6 (1 x 5 mm) can the paper not contain staples or paper clips.

We provide a warranty for the device in accordance with our general sales and delivery terms. This warranty excludes wear, damage due to improper handling, natural depreciation, and actions taken by third parties.

2. Machine components



- 1 Warning advice
- 2 LEDs
- 3 Rocker switch
- 4 Cover
- 5 Name plate
- 6 Caution label
- 7 Bottom frame
- 8 Door
- 9 Paper feed opening
- 10 Feed opening for disks and CDs

3. Safety instructions

- Read all instructions before start-up of the paper shredder. Save these instructions for later use.
- Follow all warnings and instructions marked on the product!
- Make sure no liquid is spilled on or in the paper shredder.
- If the shredder is damaged or does not function properly, switch the device off, pull out the mains plug and inform our service engineers.
- Keep paper shredder out of the reach of children.
- This shredder should be operated only with an operator in attendance.



Risk of injury!

Do not reach into the paper feed slot.




Risk of injury from slivers!

Wear protective goggles when destroying diskettes, CDs and hard credit cards.



Risk of injury by pulling in!

Keep long hair, loose articles of clothing, ties, scarves, jewellery etc. away from feed opening. Material with the tendency to form loops, e.g. tapes, strapping material, etc. must not be shredded.



Before changing the location, cleaning or anything else other than normal operation **turn off and unplug the paper shredder!**

For More Info

Click Here --->






Maintenance and service work may be performed only by:

- HSM customer service
- specially trained staff (e.g. qualified electricians)
- service technicians from our contracting partners

4. Installation

- This paper shredder should never be placed near or over a radiator or heat source.
- The ventilation slots must not be blocked or covered and they must be at a distance of at least 10 cm away from walls or furniture.
- Make sure the mains plug is easily accessible.
- Before plugging in the mains plug, check that the voltage and frequency of your local mains supply correspond to those stated on the type plate.
- After putting the collection bag in place, push the frame (with bar A pointing to the front of the cupboard) back into the guide rails.



5. Putting into operation

Switching the paper shredder on



- Press rocker switch pos. 1.
- Rocker switch locks in.
- Green LED lights.
- Paper shredder is ready for operation (standby).

Feed paper



See „Technical data“ for sheet capacity.

- The shredding process is started by a photo-cell in the paper feeding opening.
- When the paper feeding opening is free again, the cutting system automatically switches off after approx. 3 sec. and returns to standby.

Shredding CDs and disks (see “Proper Use”)



Feed CDs and disks through the slot in the safety element. This protects you from splinters.

Switching paper shredder off

- Tap rocker switch pos. 2.
- Rocker switch resets to zero position.



For More Info

Click Here --->



6. Troubleshooting

Paper jam

You have fed in too much paper.



Caution!
Do **not** press rocker switch alternately forwards/backwards (pos. 1 / pos. 2):
Cutting unit can be damaged.



- Press and hold down rocker switch pos. 2.
- Paper is pushed out.



- Separate paper stack.
- Press rocker switch pos. 1.
- Feed paper successively.

Cut material container full



- Red LED on control panel lights.
- Paper shredder switches off



Empty the cut material container, because if it is too full, malfunctions can occur in the cutting system



- Tap rocker switch pos. 2.
- Remove full shredded material bag and insert new bag.

Door contact interrupted



- Red LED on control panel lights.
- Paper shredder switches off.
- Check whether front door is closed properly.

If other faults occur, please check the following before calling our customer service:

- Is mains plug inserted?
- Is rocker switch turned on?
- Is the motor overloaded?
allow motor to cool down for 15 - 20 min.

7. Maintenance and care

Cleaning:

- Switch off the shredder, pull out the mains plug.
- When cleaning only use a soft cloth and a mild soap-water solution. Never use scouring agents, cleaning fluid, petroleum or thinners.

When the cutting capacity drops or the noise increases (Cross cut):



- Switch paper shredder off:
Tap rocker switch pos. 2.
- Spray special cutting block oil through paper feed opening across the whole width of the cutting system blades.



- Run cutting system backwards (pos. 2) without feeding paper.
- Paper dust and particles are shaken off.

8. Scope of delivery

- Paper shredder, ready for connection, in carton packing
- 5 Bags for shredded material
- Special cutting block oil 50 ml (cross cut)
- Operating instructions

Accessories:



- Bag for shredded material,
order No.: 1.330.995.000
- Special cutting block oil 250 ml,
order No.: 1.235.997.401

For More Info

Click Here --->



9. Technical Data

Cutting type	 Strip cut			 Cross cut				
	Shred size (mm)	5.8	3.9	1.9	3.9 x 30	1.9 x 15	0.78x11	1 x 5
Safety rating DIN 32757 – 1	2	2	3	3	4	5	Level 6*	
Cutting capacity (sheets) DIN A4	70 g/m ²	28 - 30	23 - 25	17 - 19	16 - 18	12 - 14	7 - 8	4 - 5
	80 g/m ²	22 - 24	18 - 20	13 - 15	12 - 14	9 - 11	6 - 7	3 - 4
Weight	26 kg			30 kg				
Noise level (Idle running/ load)	60 dB(A) / 64 dB(A)			62 dB(A) / 64 - 70 dB(A)				
Cutting speed	120 mm/s			130 mm/s				
Loading width	255 mm							
Voltage	230 V, 50 Hz 100 V, 50/60 Hz – 115 V, 60 Hz							
Power for the maximum number of sheets	670 W							
Dimensions W x D x H (mm)	448 x 347x 828							
Volume of shredded material bag	76 l							

*) HSM-specification
Technical and optical modifications reserved

For More Info

Click Here --->



Declaration of Conformity

Machinery directive 98 / 37 / EG
EMC directive 89 / 336 / EWG
Low voltage directive 73 / 23 / EWG

The manufacturer **HSM Pressen GmbH + Co. KG**, Bahnhofstraße 115, D-88682 Salem declares herewith, that the paper shredders **HSM 125.2** correspond with the aboved mentioned EC Machine Directive including all relevant modifications.

Applied standards and technical specifications:

- EN 55014-1:2000 + A1:2001 + A2:2002
- EN 55014-2:1997 + A1:2001
- EN 61000-3-2:2000
- EN 61000-3-3:1995 + A1:2001
- EN 61000-4-2:1995 + A1:1998 + A2:2001
- EN 294:1992
- EN 61000-4-4:1995 + A1:2001 + A2:2001
- EN 61000-4-5:1995 + A1:2001
- EN 61000-4-6:1996 + A1:2001
- EN 61000-4-11:1994 + A1:2001
- EN 60950-1:2001

Salem, 01.07.2003

Rolf Gasteier - Technical Director

Machine type inspection for compliance with the requirements of the EC Machine Directive was carried out by the „Administration“/Inspection Authority Committee of Experts, Subject Area „Office Machines and Devices“, on the premises of the Verwaltungs-Berufsgenossenschaft, Deelbögenkamp 4, D-22297 Hamburg. This inspection authority is the authority responsible in accordance with Annex V of the EC Machine Directive.